

CB-1400 Shop Desk

TOOLS REQUIRED FOR ASSEMBLY

Socket, ratchet, and wrench set

BEFORE ASSEMBLING THE WORKBENCH

Read through the assembly instructions to familiarize yourself with the order in which the parts are assembled.



STEP 1

The wall mounting brackets will be shipped unattached from the desk unit. Mount the brackets to the underside of the desk using (3) 1/4-20 x 1" flange head bolts and nylock nuts per bracket.



1/4-20 x 1"
Flange Head Bolt



Nylock Nut



STEP 2

Due to the weight of the desk it is recommended that it be mounted securely to a suitable structure such as a steel wall or concrete wall. If mounting to a drywall covered wall the stud structure behind the drywall must be screwed/lag bolted into.

Additional mounting holes can be drilled into the back panel of the top organizer for additional support.

Mounting will require assistance to hold it up while attaching.