

CBL CASTER RAIL

TOOLS REQUIRED FOR ASSEMBLY

Socket set w/ 1/2" socket, Open end wrench set, Cordless drill with 5/16" socket bit (Magnetic recommended), 1/8" Drill bit, & Tape measure.

BEFORE ASSEMBLING THE WORKBENCH

Assembly of this bench will require 2 people. Read through the assembly instructions to familiarize yourself with the order in which the parts are assembled. We suggest that you clear & vacuum the area where the bench is to be assembled. It is important that the bench is assembled in the same sequence as instructed.

HARDWARE & GMI COMPONENTS

All assembly hardware is provided.



STEP 1 Attach the black caster base to the bottom side of the cabinets. Use (8) 1/4-20 x3/4" flange head bolts. The bolts will thread through holes in the cabinets bottom into pre-installed nuts in the top of the caster base.

Once the base is securely bolted in place, attach the single bolt casters.

