

TOOLS REQUIRED FOR ASSEMBLY

Socket set, Open end wrench set

BEFORE ASSEMBLING THE WORKBENCH

Read through the assembly instructions to familiarize yourself with the order in which the parts are assembled. We suggest that you clear & vacuum the area where the bench is to be assembled. It is important that the bench is assembled in the same sequence as instructed.

Locate a flat & clean surface to work on. You may want to lay down a blanket to avoid scratching the tops.

Connect the two halves of your Maple top using (5) Draw Bolts.

Insert the Draw Bolts in the routed slots as shown in Figure 1.

Hold the bolt head in place and tighten the nut on the opposite end to draw the steel plates tight and secure the two halves of the work surface.

Make sure the 2 tops are even before you fully tighten the bolts.

