

GBT Weld Tester

TOOLS REQUIRED FOR ASSEMBLY

3/8" Socket Wrench & 3/8" Crescent Wrench, Phillips Head Screwdriver.

BEFORE ASSEMBLING THE WORKBENCH

Read through the assembly instructions to familiarize yourself with the order in which the parts are assembled.

HARDWARE

All Assembly Hardware is Provided. Floor Mount Hardware Not Provided.



TEP 1

Attach guard to guard plate using the provided #8-32 screws(2) and nylock nuts(2).



