



BLUM STYLE HINGE ADJUSTMENT

Three-dimensional adjustment



Side adjustment

Rotate front screw to increase or decrease door overlay (± 2 mm).



Height adjustment

Rotate cam screw on mounting plate to adjust door position (± 2 mm).



Depth adjustment

Rotate rear spiral tech cam screw to adjust door gap ($+3$ mm, -2 mm).

