

Locker Assembly

TOOLS REQUIRED FOR ASSEMBLY

Phillips Head screw driver, Open end wrench.

BEFORE ASSEMBLING THE WORKBENCH



Read through the assembly instructions to familiarize yourself with the order in which the parts are assembled.

We suggest that you clear & vacuum the area where the lockers are to be assembled.

It is important that the lockers are assembled in the same sequence as instructed.

HARDWARE

All assembly hardware is provided.



BE CAREFUL OF TIPPING WHEN HANDLING LOCKER
WHILE NOT ATTACHED TO THE WALL.

STEP 1


Begin by attaching the back corner upright braces to the back panel as shown. Use the provided 10-32x 3/8" Pan head machine screws and nuts. Secure the panels bolting through from the backside so that the bolt head is to the outside of the locker.



#10-32x3/8
NUT



#8-32x1/2
PAN HEAD SCREW



STEP 2


Install the top/bottom shelves and center shelf as shown. Secure the shelves to the back panel using the provided 10-32x 3/8" Pan head machine screws and nuts. Secure the panels bolting through from the outside so that the bolt head is to the outside of the locker.



#10-32x3/8
NUT



#8-32x1/2
PAN HEAD SCREW



STEP 3


Install the side panel as shown. The flange of the side panel will slip inside of the back panel and outside of the top/bottom panels. Secure the side panel to the back panel, top/bottom, and the shelf using the provided 10-32x 3/8" Pan head machine screws and nuts. Secure the panels bolting through from the outside so that the bolt head is to the outside of the locker.



#10-32x3/8
NUT



#8-32x1/2
PAN HEAD SCREW



STEP 4

Insert the opposite side panel as shown. The side panel will slip inside of the back panel flange and outside of the top/bottom panels. If you are assembling a series of lockers do not attach the side panel yet.






Figure 4.1



Detail B

STEP 5

Lower the door frame assembly as shown. The side panels will slip inside of the frame assembly. Attach the door frame assembly using the provided 10-32x 3/8" Pan head machine screws and nuts in all locations with the exception of the bottom panel. In these 2 locations use the provided 10-32x3/8 Flat head bolts. Secure the panels bolting through from the outside so that the bolt head is to the outside of the locker. Do not attach the right side of the door frame if the locker is the starter of a series.



Detail C




Figure 5.3



#10-32x3/8
FLAT HEAD SCREW




Figure 5.1





Figure 5.2



Detail D

STEP 6

Continue with the series of lockers by repeating Steps 1 and 2. Position the back panel with the top, bottom and divider as shown. Bolt through both back panels and the divider reaching inside the adjacent cabinet. Repeat this procedure for the top, bottom and divider shelf.




Figure 6.1

STEP 7

Insert another side panel as shown in Step 4. With the side panel positioned in place lower another door frame into position as shown in Step 5. Once in place use the provided #10-32 x 3/8" pan head screws to bolt through both door frames and the divider panel.




Figure 7.1




Figure 7.2

STEP 8

Installers may choose to assemble lockers in groups of 3-4 and connecting the groups together once they are near their final position as opposed to assembling the entire run of lockers and carefully moving into position. Lockers without leg bases can be difficult in this operation as you need access to the bottom of the locker to attach the bottom panel. You may choose to use 4x4 wood blocks to act as a riser to create enough space to bolt the cabinets together.

Take care and have at least one other person assist with this step as there is a risk of tipping while lockers are not secured to the wall.

BE CAREFUL OF TIPPING WHEN HANDLING LOCKER WHILE NOT ATTACHED TO THE WALL.




Figure 8.1




Figure 8.2