

GS-1860-R Assembly Instructions

TOOLS REQUIRED FOR ASSEMBLY


Cordless drill with 3/8" Magnetic socket bit.

BEFORE ASSEMBLING THE WORKBENCH

Read through the assembly instructions to familiarize yourself with the order in which the parts are assembled. We suggest that you clear & vacuum the area where the bench is to be assembled. It is important that the bench is assembled in the same sequence as instructed.

HARDWARE & GMI COMPONENTS

All assembly hardware is provided. Full size photos accompany each step where hardware is needed.




STEP 1

Locate the correct legs for the table you wish to assemble. Measure the base tube. It should be 18"L. The mounting plate is flat


Screw 2 chrome levelers into each leg.

Attach the counter support brace to each leg using (2) 1/4-20 x 1/2" Flange Head Bolts per leg. Indicated by the red arrow.



STEP 2

Carefully lay the work surface face down on the ground (or work table).



STEP 3

Center the leg assembly front-to-back and side-to-side.

Attach the base to the work surface using #14 x 1" Lag Screws. (4 per leg). And (4) lags through the top support brace

Turn the bench right-side-up. Assembly is complete.

