

TG-GMR DESK

TOOLS REQUIRED FOR ASSEMBLY

Electric Hand Drill, Phillips Head Bit, 3/8" Magnetic Hex Driver Bit, Socket Set and Ratchet.

BEFORE ASSEMBLING THE WORKBENCH


Read through the assembly instructions to familiarize yourself with the order in which the parts are assembled.

We suggest that you clear & vacuum the area where the bench is to be assembled.

It is important that the bench is assembled in the same sequence as instructed.


HARDWARE

All assembly hardware is provided.




STEP 1

On a clean surface or blanket lay the top bottom side up. Attach the legs using (6) #14 x 1" lag bolts per leg.




STEP 2

Attach the top support brace using (14) #10 x 5/8" SPAX wood screws. Center the brace between the two legs.




STEP 3

Attach the modesty panel using (6) #10 x 5/8" SPAX wood screws. Once attached, flip the table right side up.




STEP 4

The shelf support risers will be shipped in three pieces. Attach the back panel to the two sides using (2) #8 x 5/8" black sheet metal screws per side.




STEP 5

Position the riser assembly on the desks top, take care not to scratch the work surface. There are 4 predrilled holes through the work surface. Insert (1) 1/4 x 2" bolt, (1) lock washer, and (1) flat washer in from the bottom of the work surface and thread up into the pre-installed nuts on the bottom of the risers. Do this for all 4 mounting holes.



STEP 6

Position the upper shelf on the risers. Center the shelf side-to-side and line the back edge of the shelf so it is even with the back edge of the main work surface. Attach using (12) #10 x 5/8" Spax wood screws by screwing into the underside of the shelf.



STEP 7

Insert wire grommets. Your desk is now complete.

Note: If your floor is uneven the desk can be levelled by adjusting the installed foot pad levellers.

