

WORKBENCH ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED FOR ASSEMBLY


Cordless drill with, 3/8" Magnetic socket bit,
5/16" Magnetic socket bit, 18" magnetic extension.

BEFORE ASSEMBLING THE WORKBENCH

Read through the assembly instructions to familiarize yourself with the order in which the parts are assembled. We suggest that you clear & vacuum the area where the bench is to be assembled. It is important that the bench is assembled in the same sequence as instructed.

HARDWARE & GMI COMPONENTS

All assembly hardware is provided. Full size photos accompany each step where hardware is needed.




STEP 1

Assemble the modesty panel to the base cabinets and pedestal leg. Use four 1/4-20 x 1/2" Flange Head Bolts using the 3/8" magnetic socket.

****Your base cabinets may be different than those shown. Follow the same instructions****




1/4-20 x 1/2"
Flange Head Bolt



STEP 2

Hook the (Optional) wire management tray over the top lip of the modesty panel.



STEP 3


Set the top on the assembled base.
Adjust the top to leave no more than a two inch overhang in the front and even gaps on the left and right side.

Attach the top to the leg pedestal & cabinet
#14 x 1" Lag bolts with the 3/8" magnetic socket.
(You must remove the top drawer(s) from drawer cabinets). Leg pedestals use 6 screws.
Cabinets use 4 screws.

For longer width tops an additional support brace will be provided as shown. Use (2) 1/4-20 x 1/2" bolts and attach loosely at each end into the pre-installed nuts on the side of the cabinet or leg. Once top is installed use #14 x 1" Lag bolts and fasten from the bottom side. Tighten the 1/4-20 x 1/2" bolts.



#14 x 1"
Lag Bolt



STEP 4

Optional Foot Brace
Attach the lower cross support / foot rest to the leg assemblies. Attach using (4) 1/4-20 x 1/2" flange head bolts.



1/4-20 x 1/2"
Flange Head Bolt

